



**SURVIVAL PRODUCTS**

Established 1920

**UA-80 EVOLUTION™**

**CONSTANT WEAR LIFE VEST**



**Orientation and Operation**



1. Inflation handle
2. Outer Cover with Breakaway Zipper Closure
3. COBRA Buckle
4. Strap Stowage Pockets
5. Survivor Locator Light
6. Donning Procedure Pictogram



7. Flotation Bladder
8. Operating Procedure Pictogram
9. Oral Inflation Tubes
10. CO2 Cylinders
11. Grab Handle
12. Retroreflective Material
13. Nameplate Velcro



- 6
- 8



The **UA-80 EVOLUTION** constant wear life vest is an encapsulated flotation device designed for constant wear while in an aircraft. The buoyancy chamber has manual CO<sub>2</sub> inflators and secondary oral inflation tubes. The vest is approved under TSO-C13g.

For more information, please visit our website: [www.switlik.com](http://www.switlik.com)

### Donning Instructions

1. See Donning Instruction pictogram on the inside-front of the vest.
2. Put vest on by loosening the straps on the "X" adjuster. Slip on over the head.

### CAUTION: Do Not Vest Under Clothing

3. Adjust back straps on each side by pulling the loose ends down and forward. The vest should be snug against the body.
4. Fold and tuck excess straps, as necessary, into strap stowage pockets.
5. To doff the vest, unclip the buckle on the left-hand side. The vest can now be pulled over the head.



Adjust back straps on each side

### Inflation and Use Instructions

1. See Operating Instruction pictogram on the inside-front of the vest.
2. Do not inflate life vest while inside the aircraft.
3. After exiting the aircraft, locate and grab the beaded inflation handle with both hands. Pull sharply away from the body.
4. Oral inflation tubes are located on the left side and right side of the bladder. Remove from Velcro keepers and blow into them for secondary inflation method.
5. The underarm flotation bladder will wrap around the body and sit underneath the arms.



Stow straps in pockets



Pull sharply with both hands to inflate

